



Complete Gas Injection Kit

Complete Gas Injection Kit for the Extrima, Ex-certified Hydrogen Leak Detector

The Complete Gas Injection Kit is an accessory to the [Extrima, Ex-certified Hydrogen Leak detector](#), for injecting tracer gas into fuel leaks during maintenance of aircrafts. The kit includes a complete set of accessories that you need for efficient leak detection in many different kind of situations, all delivered in a smart and heavy-duty transport case. The equipment includes Injection Pads, Injection Fix Kit and Injection Panel which incorporates a certified leak for calibration of the detector.

Accessories included (or offered separately) in the Complete Gas Injection Kit:

Injection Pads

During leak detection the Injection Pads are used to inject tracer gas via the leak exit point. When the gas has been injected, the Ex-certified leak detector Extrima is recommended for pin-pointing the leak on the fuel system. The pads are available in sizes Small (60 mm) and Large (150 mm).

Injection Fix Kit

When fuel leaks are found in tricky places, the Injection Fix Kit allows for adapting the injection tool to a specific situation. The kit includes PVC tubes, cutter, aluminum tape, injection plug, mylar film and sealant tape.

Injection Panel

The Injection Panel is the complete Gas Injection Kit without the Injection Pads and the Injection Fix Kit.



BENEFITS

- Makes back tracing aircraft fuel leaks controlled and efficient
- Can be operated by one operator
- Includes all you need between the tracer gas bottle and the leak
- Helps keep your detector calibrated
- Delivered in a durable and heavy-duty transport case

FEATURES

- Accessory to the Extrima, Ex-certified Hydrogen Leak Detector
- Includes Injection Pads which are used to inject tracer gas via the leak exit point
- Includes the Injection Fix Kit, the easiest way to find leaks when they are located on uneven surfaces
- Includes the Injection Panel, for easy tracer gas injection from bottle to Injection Pads, check the pressure and that your instrument is calibrated
- The Injection Pads, Injection Fix Kit and the Injection Panel can also be delivered separately

ORDER INFORMATION

| Type | Complete Gas Injection Kit |
|--|----------------------------|
| Complete Gas Injection Kit (incl. Injection Panel, Injection Fix Kit and Injection Pads) | 590-621 |
| Injection Fix Kit, for injecting tracer gas to leaks on uneven surfaces | 590-618 |
| Injection Pads Large, 150 mm, 10 pcs (for filling tracer gas into fuel tanks) | 590-616 |
| Injection Pads Small, 60 mm, 10 pcs (for filling tracer gas into fuel tanks) | 590-615 |
| Injection Panel, for easy gas injection from bottle to Injection Pad | 590-619 |



www.inficon.com reachus@inficon.com

Due to our continuing program of product improvements, specifications are subject to change without notice. RateWatcher is a trademark of INFICON. All other trademarks are the property of their respective owners.

(2018-07) © 2018 INFICON